


# STAGE DIMENSIONS



The Pantages Theatre has a sprung Maple floor.  
(Installation completed 1/31/2006)

SR: 29' 3"

**Proscenium Opening:** 33' 10" wide x 30" high

## Stage Depth

Lip of apron to plaster line:

49½" at center

33½" at offstage edges

Lip of apron to back wall columns: 28' 11½"

Depth of smoke pocket: 6"

Curtain line to back wall columns: 23'

Proscenium wall to back wall columns: 24' 10"

## Plaster line center stage to:

First row of seats: 17' 6"

Mix position: 70' (18' wide)

Rear wall main floor: 78'

Balcony box boom: 56' 8"

Balcony rail center: 36'

Balcony rail sides: 38'

Booth: 90' 10"

Rear wall balcony: 104'

## Stage Width

SR to SL, unobstructed: 58' 9"

SL Wing: 12' 5"

SR Wing: 12' 5"

## Distance from center stage to:

SL: 29' 6"